



AS YOU TIGHTEN THE 12mm BOLT
 THE DAMPING CARTRIDGE WILL BE
 DRAWN DEEPER INTO THE STEER
 TUBE. YOU MUST ALLOW FOR THIS
 MOTION TO OCCUR
 □
 VERIFY THAT THE 35mm NUT, THE
 THREADS THAT THE NUT RIDES ON
 OR THE POST DO NOT INHIBIT THE
 REQUIRED MOTION. THE THREADS
 □
 GENERALLY DO NOT NEST INTO AN
 TIGHTENED STEM. □